



Brought to you by **FUJITSU**

Service

BULLETIN

S007D

August 2017

Outdoor Unit Dip Switch Settings

When installing a Fujitsu Airstage VRF system, the installing contractor must determine the proper dip-switch and dial settings for all indoor units, outdoor units, controls and other accessories. These settings, which control features such as external inputs, fan speed, addressing, and communications, will be different for almost every installation.

While some settings will be different, the dip-switch settings on the outdoor units will be mostly the same based on the size of the system. The “terminal resistor” setting on the Master Unit will need to be determined when setting the outdoor unit dip-switches.

The following diagrams show the settings for a simple VRF system where all indoor and outdoor units are on the same refrigerant circuit and the communication network does not include a signal amplifier.

Dip switch settings can also be different between Heat Pump and Heat Recovery systems as well as the different voltage systems. When using this bulletin, always make sure to use the proper settings for the correct system model, voltage, and size.

Warning

If a network segment contains more than one refrigerant circuit, or if a signal amplifier is used, DO NOT use Dip SW SET5-4 settings listed in this bulletin. Instead, refer to the Installation manual Section 7 "FIELD SETTING" or the D&T Manual Chapter 7 Section 1-6 "TERMINAL RESISTOR SETTING" to properly set Dip-SW SET5-4 of the Master unit

Caution

Be sure to set the terminal resistor according to specifications.
Set the terminal resistor for every network segments (NS).

- If terminal resistor is set in multiple devices, the overall communication system may be damaged.
- If terminal resistor is not set in a device, abnormal communication may occur.



Brought to you by **FUJITSU**

Service

BULLETIN

S007D

August 2017

Table of Contents

| | |
|---|----|
| J-IIS Heat Pump (208/230V – 1 Phase) | 5 |
| J-IIS Heat Pump (230V – 1 Phase) – (3 TON) AOU36RLAVS | 5 |
| J-IIS Heat Pump (230V – 1 Phase) – (4 TON) AOU48RLAVS | 5 |
| J-II Heat Pump (208/230V – 1 Phase) | 6 |
| J-II Heat Pump (230V – 1 Phase) – (3 TON) AOU36RLAVM | 6 |
| J-II Heat Pump (230V – 1 Phase) – (4 TON) AOU48RLAVM | 6 |
| J-II Heat Pump (230V – 1 Phase) – (5 TON) AOU60RLAVM | 7 |
| V-II Heat-Pumps (208/230V - 3 Phase) | 8 |
| Heat-Pump (208/230V – 3 Phase) - (6 TONS) AOUA72RLBV1 | 8 |
| Heat-Pump (208/230V – 3 Phase) - (8 TONS) AOUA96RLBV1 | 8 |
| Heat-Pump (208/230V – 3 Phase) - (10 TONS) AOUA120RLBV1 | 9 |
| Heat-Pump (208/230V – 3 Phase) - (12 TONS) AOUA144RLBV1 | 9 |
| Heat-Pump (208/230V – 3 Phase) - (14 TONS) AOUA168RLBV1 | 10 |
| Heat-Pump (208/230V – 3 Phase) - (16 TONS) AOUA192RLBV1 | 10 |
| Heat-Pump (208/230V – 3 Phase) - (18 TONS) AOUA216RLBV1 | 11 |
| Heat-Pump (208/230V – 3 Phase) - (20 TONS) AOUA240RLBV1 | 11 |
| Heat-Pump (208/230V – 3 Phase) - (22 TONS) AOUA264RLBV1 | 12 |
| Heat-Pump (208/230V – 3 Phase) - (24 TONS) AOUA288RLBV1 | 12 |
| V-II Heat-Pumps (208/230V - 3 Phase) – Old model RLBV | 14 |
| Heat-Pump (208/230V – 3 Phase) - (6 TONS) AOUA72RLBV | 14 |
| Heat-Pump (208/230V – 3 Phase) - (8 TONS) AOUA96RLBV | 14 |
| Heat-Pump (208/230V – 3 Phase) - (12 TONS) AOUA144RLBVG | 15 |
| Heat-Pump (208/230V – 3 Phase) - (14 TONS) AOUA168RLBVG | 15 |
| Heat-Pump (208/230V – 3 Phase) - (16 TONS) AOUA192RLBVG | 16 |
| Heat-Pump (208/230V – 3 Phase) - (18 TONS) AOUA216RLBVG | 16 |
| Heat-Pump (208/230V – 3 Phase) - (20 TONS) AOUA240RLBVG | 17 |
| Heat-Pump (208/230V – 3 Phase) - (22 TONS) AOUA264RLBVG | 17 |



Brought to you by **FUJITSU**

Service

BULLETIN

S007D

August 2017

| | |
|--|----|
| Heat-Pump (208/230V – 3 Phase) - (24 TONS) AOUA288RLBVG | 18 |
| V-II Heat-Pumps (460V – 3 Phase)..... | 19 |
| Heat-Pump (460V – 3 Phase) - (6 TONS) AOUA72RLCV..... | 19 |
| Heat-Pump (460V – 3 Phase) - (8 TONS) AOUA96RLCV..... | 19 |
| Heat-Pump (460V – 3 Phase) - (10 TONS) AOUA120RLCV..... | 20 |
| Heat-Pump (460V – 3 Phase) - (12 TONS) AOUA144RLCVG | 20 |
| Heat-Pump (460V – 3 Phase) - (14 TONS) AOUA168RLCVG | 21 |
| Heat-Pump (460V – 3 Phase) - (16 TONS) AOUA192RLCVG | 21 |
| Heat-Pump (460V – 3 Phase) - (18 TONS) AOUA216RLCVG | 22 |
| Heat-Pump (460V – 3 Phase) - (20 TONS) AOUA240RLCVG | 22 |
| Heat-Pump (460V – 3 Phase) - (22 TONS) AOUA264RLCVG | 23 |
| Heat-Pump (460V – 3 Phase) - (24 TONS) AOUA288RLCVG | 23 |
| VR-II Heat Recovery (208/230V – 3 Phase)..... | 25 |
| Heat Recovery (208/230V – 3 Phase) - (6 TONS) AOUA72TLBV | 25 |
| Heat Recovery (208/230V – 3 Phase) - (8 TONS) AOUA96TLBV | 25 |
| Heat Recovery (208/230V – 3 Phase) - (10 TONS) AOUA120TLBV | 26 |
| Heat Recovery (208/230V – 3 Phase) - (12 TONS) AOUA144TLBVG..... | 26 |
| Heat Recovery (208/230V – 3 Phase) - (14 TONS) AOUA168TLBVG..... | 27 |
| Heat Recovery (208/230V – 3 Phase) - (16 TONS) AOUA192TLBVG..... | 27 |
| Heat Recovery (208/230V – 3 Phase) - (18 TONS) AOUA216TLBVG..... | 28 |
| Heat Recovery (208/230V – 3 Phase) - (20 TONS) AOUA240TLBVG..... | 28 |
| Heat Recovery (208/230V – 3 Phase) - (22 TONS) AOUA264TLBVG..... | 29 |
| Heat Recovery (208/230V – 3 Phase) - (24 TONS) AOUA288TLBVG..... | 29 |
| VR-II Heat Recovery (460V – 3 Phase) | 31 |
| Heat Recovery (460V – 3 Phase) - (6 TONS) AOUA72TLCV..... | 31 |
| Heat Recovery (460V – 3 Phase) - (8 TONS) AOUA96TLCV..... | 31 |
| Heat Recovery (460V – 3 Phase) - (10 TONS) AOUA120TLCV..... | 32 |
| Heat Recovery (460V – 3 Phase) - (12 TONS) AOUA144TLCVG | 32 |



Brought to you by **FUJITSU**

Service

BULLETIN

S007D

August 2017

| | |
|---|----|
| Heat Recovery (460V – 3 Phase) - (14 TONS) AOUA168TLCVG | 33 |
| Heat Recovery (460V – 3 Phase) - (16 TONS) AOUA192TLCVG | 33 |
| Heat Recovery (460V – 3 Phase) - (18 TONS) AOUA216TLCVG | 34 |
| Heat Recovery (460V – 3 Phase) - (20 TONS) AOUA240TLCVG | 34 |
| Heat Recovery (460V – 3 Phase) - (22 TONS) AOUA264TLCVG | 35 |
| Heat Recovery (460V – 3 Phase) - (24 TONS) AOUA288TLCVG | 35 |


S007D

August 2017

J-IIS Heat Pump (208/230V – 1 Phase)


J-IIS Heat Pump (230V – 1 Phase) – (3 TON) AOU36RLAVS

3 Ton Master unit



J-IIS Heat Pump (230V – 1 Phase) – (4 TON) AOU48RLAVS

4 Ton Master unit



See Dip-SW SET5-4 and SET4-1 option on page 7.


S007D

August 2017

J-II Heat Pump (208/230V - 1 Phase)


J-II Heat Pump (230V - 1 Phase) - (3 TON) AOU36RLAVM

3 Ton Master unit



J-II Heat Pump (230V - 1 Phase) - (4 TON) AOU48RLAVM

4 Ton Master unit




See Dip-SW SET5-4 and SET4-1 option on page 7.

S007D

August 2017

I-II Heat Pump (230V – 1 Phase) – (5 TON) AOU60RLAVM

5 Ton Master unit



* Dip-SW SET5-4 diagrams are only used with one refrigerant system configuration. When there are more than one refrigerant systems on a communication network, confirm that the setting of Dip-SW SET5-4 complies with the Terminal Resistor requirements in the Installation Manual.

** Dip-SW SET4-1 in all Airstage outdoor units, except V-II 208/230V-3 Phase RLVB, provides a system protection function that is activated by default from the factory. When activated, Dip-SW SET4-1 is ON, the system will shut down whenever an indoor unit fails. If Dip-SW SET4-1 is set to OFF, a failure in an indoor unit will display error and the system will continue its normal operation. The activation of Dip-SW SET4-1 is crucial to VRF equipment protection. Under extreme conditions Fujitsu allows the de-activation of Dip-SW SET4-1 **ONLY AFTER closing the Isolation Valve/Ball Valve** connecting the failed indoor unit to the refrigerant system. Please refer to AE015 Bulletin for Isolation Ball Valves for proper installation of Isolation Ball valves in Heat Pump and Heat Recovery systems. The de-activation of Dip-SW SET4-1 without closing the indoor unit Isolation Valve/Ball Valve shall void the outdoor unit warranty. It is important to activate Dip-SW SET4-1 again immediately after the indoor unit failure has been rectified.

See Dip-SW SET5-4 and SET4-1 option on page 7.


S007D

August 2017

V-II Heat-Pumps (208/230V - 3 Phase)


[Heat-Pump \(208/230V - 3 Phase\) - \(6 TONS\) AOUA72RLBV1](#)

6 Ton Master unit



[Heat-Pump \(208/230V - 3 Phase\) - \(8 TONS\) AOUA96RLBV1](#)

8 Ton Master unit




See Dip-SW SET5-4 and SET4-1 option on page 13.

S007D

August 2017

[Heat-Pump \(208/230V – 3 Phase\) - \(10 TONS\) AOUA120RLBV1](#)


10 Ton Master unit



[Heat-Pump \(208/230V – 3 Phase\) - \(12 TONS\) AOUA144RLBV1](#)

6 Ton Master unit

6 Ton Slave unit1




See Dip-SW SET5-4 and SET4-1 option on page 13.


S007D

August 2017

[Heat-Pump \(208/230V – 3 Phase\) - \(14 TONS\) AOUA168RLBV1](#)



[Heat-Pump \(208/230V – 3 Phase\) - \(16 TONS\) AOUA192RLBV1](#)




See Dip-SW SET5-4 and SET4-1 option on page 13.

©2017 Fujitsu General America, Inc.


S007D

August 2017

Heat-Pump (208/230V – 3 Phase) - (18 TONS) AOUA216RLBV1



Heat-Pump (208/230V – 3 Phase) - (20 TONS) AOUA240RLBV1




See Dip-SW SET5-4 and SET4-1 option on page 13.

©2017 Fujitsu General America, Inc.


S007D

August 2017

Heat-Pump (208/230V – 3 Phase) - (22 TONS) AOUA264RLBV1



Heat-Pump (208/230V – 3 Phase) - (24 TONS) AOUA288RLBV1



See Dip-SW SET5-4 and SET4-1 option on page 13.

©2017 Fujitsu General America, Inc.



Brought to you by **FUJITSU**

Service

BULLETIN

S007D

August 2017

* Dip-SW SET5-4 diagrams are only used with one refrigerant system configuration. When there are more than one refrigerant systems on a communication network, confirm that the setting of Dip-SW SET5-4 complies with the Terminal Resistor requirements in the Installation Manual.


** Dip-SW SET4-1 in all Airstage outdoor units, except V-II 208/230V-3 Phase RLBV, provides a system protection function that is activated by default from the factory. When activated, Dip-SW SET4-1 is ON, the system will shut down whenever an indoor unit fails. If Dip-SW SET4-1 is set to OFF, a failure in an indoor unit will display error and the system will continue its normal operation. The activation of Dip-SW SET4-1 is crucial to VRF equipment protection. Under extreme conditions Fujitsu allows the de-activation of Dip-SW SET4-1 **ONLY AFTER closing the Isolation Valve/Ball Valve** connecting the failed indoor unit to the refrigerant system. Please refer to AE015 Bulletin for Isolation Ball Valves for proper installation of Isolation Ball valves in Heat Pump and Heat Recovery systems. The de-activation of Dip-SW SET4-1 without closing the indoor unit Isolation Valve/Ball Valve shall void the outdoor unit warranty. It is important to activate Dip-SW SET4-1 again immediately after the indoor unit failure has been rectified.

S007D


August 2017

V-II Heat-Pumps (208/230V - 3 Phase) – Old model RLBV

Heat-Pump (208/230V – 3 Phase) - (6 TONS) AOUA72RLBV



Heat-Pump (208/230V – 3 Phase) - (8 TONS) AOUA96RLBV




See Dip-SW SET5-4 and SET4-1 option on page 18.


S007D

August 2017

Heat-Pump (208/230V – 3 Phase) - (12 TONS) AOUA144RLBVG



Heat-Pump (208/230V – 3 Phase) - (14 TONS) AOUA168RLBVG




See Dip-SW SET5-4 and SET4-1 option on page 18.


S007D

August 2017

Heat-Pump (208/230V – 3 Phase) - (16 TONS) AOUA192RLBVG



Heat-Pump (208/230V – 3 Phase) - (18 TONS) AOUA216RLBVG




See Dip-SW SET5-4 and SET4-1 option on page 18.


S007D

August 2017

Heat-Pump (208/230V – 3 Phase) - (20 TONS) AOUA240RLBVG



Heat-Pump (208/230V – 3 Phase) - (22 TONS) AOUA264RLBVG




See Dip-SW SET5-4 and SET4-1 option on page 18.

©2017 Fujitsu General America, Inc.

S007D

August 2017

Heat-Pump (208/230V – 3 Phase) - (24 TONS) AOUA288RLBVG



* Dip-SW SET5-4 diagrams are only used with one refrigerant system configuration. When there are more than one refrigerant systems on a communication network, confirm that the setting of Dip-SW SET5-4 complies with the Terminal Resistor requirements in the Installation Manual.

** Dip-SW SET4-1 in all Airstage outdoor units, except V-II 208/230V-3 Phase RLBV, provides a system protection function that is activated by default from the factory. When activated, Dip-SW SET4-1 is ON, the system will shut down whenever an indoor unit fails. If Dip-SW SET4-1 is set to OFF, a failure in an indoor unit will display error and the system will continue its normal operation. The activation of Dip-SW SET4-1 is crucial to VRF equipment protection. Under extreme conditions Fujitsu allows the de-activation of Dip-SW SET4-1 **ONLY AFTER closing the Isolation Valve/Ball Valve** connecting the failed indoor unit to the refrigerant system. Please refer to AE015 Bulletin for Isolation Ball Valves for proper installation of Isolation Ball valves in Heat Pump and Heat Recovery systems. The de-activation of Dip-SW SET4-1 without closing the indoor unit Isolation Valve/Ball Valve shall void the outdoor unit warranty. It is important to activate Dip-SW SET4-1 again immediately after the indoor unit failure has been rectified.


See Dip-SW SET5-4 and SET4-1 option on page 18.

S007D


August 2017

V-II Heat-Pumps (460V - 3 Phase)

Heat-Pump (460V – 3 Phase) - (6 TONS) AOUA72RLCV



Heat-Pump (460V – 3 Phase) - (8 TONS) AOUA96RLCV




See Dip-SW SET5-4 and SET4-1 option on page 24.


S007D

August 2017

Heat-Pump (460V – 3 Phase) - (10 TONS) AOUA120RLCV



Heat-Pump (460V – 3 Phase) - (12 TONS) AOUA144RLCVG




See Dip-SW SET5-4 and SET4-1 option on page 24.


S007D

August 2017

Heat-Pump (460V – 3 Phase) - (14 TONS) AOUA168RLCVG



Heat-Pump (460V – 3 Phase) - (16 TONS) AOUA192RLCVG




See Dip-SW SET5-4 and SET4-1 option on page 24.

©2017 Fujitsu General America, Inc.


S007D

August 2017

Heat-Pump (460V – 3 Phase) - (18 TONS) AOUA216RLCVG



Heat-Pump (460V – 3 Phase) - (20 TONS) AOUA240RLCVG




See Dip-SW SET5-4 and SET4-1 option on page 24.


S007D

August 2017

Heat-Pump (460V – 3 Phase) - (22 TONS) AOUA264RLCVG



Heat-Pump (460V – 3 Phase) - (24 TONS) AOUA288RLCVG



See Dip-SW SET5-4 and SET4-1 option on page 24.

©2017 Fujitsu General America, Inc.



Brought to you by **FUJITSU**

Service

BULLETIN

S007D

August 2017

* Dip-SW SET5-4 diagrams are only used with one refrigerant system configuration. When there are more than one refrigerant systems on a communication network, confirm that the setting of Dip-SW SET5-4 complies with the Terminal Resistor requirements in the Installation Manual.

** Dip-SW SET4-1 in all Airstage outdoor units, except V-II 208/230V-3 Phase RL BV, provides a system protection function that is activated by default from the factory. When activated, Dip-SW SET4-1 is ON, the system will shut down whenever an indoor unit fails. If Dip-SW SET4-1 is set to OFF, a failure in an indoor unit will display error and the system will continue its normal operation. The activation of Dip-SW SET4-1 is crucial to VRF equipment protection. Under extreme conditions Fujitsu allows the de-activation of Dip-SW SET4-1 **ONLY AFTER closing the Isolation Valve/Ball Valve** connecting the failed indoor unit to the refrigerant system. Please refer to AE015 Bulletin for Isolation Ball Valves for proper installation of Isolation Ball valves in Heat Pump and Heat Recovery systems. The de-activation of Dip-SW SET4-1 without closing the indoor unit Isolation Valve/Ball Valve shall void the outdoor unit warranty. It is important to activate Dip-SW SET4-1 again immediately after the indoor unit failure has been rectified.


S007D

August 2017

VR-II Heat Recovery (208/230V – 3 Phase)


Heat Recovery (208/230V – 3 Phase) - (6 TONS) AOUA72TLBV

6 Ton Master unit



Heat Recovery (208/230V – 3 Phase) - (8 TONS) AOUA96TLBV

8 Ton Master unit




See Dip-SW SET5-4 and SET4-1 option on page 30.

©2017 Fujitsu General America, Inc.


S007D

August 2017

Heat Recovery (208/230V – 3 Phase) - (10 TONS) AOUA120TLBV



Heat Recovery (208/230V – 3 Phase) - (12 TONS) AOUA144TLBVG




See Dip-SW SET5-4 and SET4-1 option on page 30.

©2017 Fujitsu General America, Inc.


S007D

August 2017

Heat Recovery (208/230V – 3 Phase) - (14 TONS) AOUA168TLBVG



Heat Recovery (208/230V – 3 Phase) - (16 TONS) AOUA192TLBVG




See Dip-SW SET5-4 and SET4-1 option on page 30.

©2017 Fujitsu General America, Inc.


S007D

August 2017

Heat Recovery (208/230V – 3 Phase) - (18 TONS) AOUA216TLBVG



Heat Recovery (208/230V – 3 Phase) - (20 TONS) AOUA240TLBVG




See Dip-SW SET5-4 and SET4-1 option on page 30.

©2017 Fujitsu General America, Inc.


S007D

August 2017

Heat Recovery (208/230V – 3 Phase) - (22 TONS) AOUA264TLBVG



Heat Recovery (208/230V – 3 Phase) - (24 TONS) AOUA288TLBVG



See Dip-SW SET5-4 and SET4-1 option on page 30.

©2017 Fujitsu General America, Inc.



Brought to you by **FUJITSU**

Service

BULLETIN

S007D

August 2017

* Dip-SW SET5-4 diagrams are only used with one refrigerant system configuration. When there are more than one refrigerant systems on a communication network, confirm that the setting of Dip-SW SET5-4 complies with the Terminal Resistor requirements in the Installation Manual.


** Dip-SW SET4-1 in all Airstage outdoor units, except V-II 208/230V-3 Phase RLBV, provides a system protection function that is activated by default from the factory. When activated, Dip-SW SET4-1 is ON, the system will shut down whenever an indoor unit fails. If Dip-SW SET4-1 is set to OFF, a failure in an indoor unit will display error and the system will continue its normal operation. The activation of Dip-SW SET4-1 is crucial to VRF equipment protection. Under extreme conditions Fujitsu allows the de-activation of Dip-SW SET4-1 **ONLY AFTER closing the Isolation Valve/Ball Valve** connecting the failed indoor unit to the refrigerant system. Please refer to AE015 Bulletin for Isolation Ball Valves for proper installation of Isolation Ball valves in Heat Pump and Heat Recovery systems. The de-activation of Dip-SW SET4-1 without closing the indoor unit Isolation Valve/Ball Valve shall void the outdoor unit warranty. It is important to activate Dip-SW SET4-1 again immediately after the indoor unit failure has been rectified.

S007D


August 2017

VR-II Heat Recovery (460V – 3 Phase)

Heat Recovery (460V – 3 Phase) - (6 TONS) AOUA72TLCV



Heat Recovery (460V – 3 Phase) - (8 TONS) AOUA96TLCV




See Dip-SW SET5-4 and SET4-1 option on page 36.


S007D

August 2017

Heat Recovery (460V – 3 Phase) - (10 TONS) AOUA120TLCV



Heat Recovery (460V – 3 Phase) - (12 TONS) AOUA144TLCVG




See Dip-SW SET5-4 and SET4-1 option on page 36.


S007D

August 2017

Heat Recovery (460V – 3 Phase) - (14 TONS) AOUA168TLCVG



Heat Recovery (460V – 3 Phase) - (16 TONS) AOUA192TLCVG




See Dip-SW SET5-4 and SET4-1 option on page 36.


S007D

August 2017

Heat Recovery (460V – 3 Phase) - (18 TONS) AOUA216TLCVG



Heat Recovery (460V– 3 Phase) - (20 TONS) AOUA240TLCVG




See Dip-SW SET5-4 and SET4-1 option on page 36.


S007D

August 2017

Heat Recovery (460V – 3 Phase) - (22 TONS) AOUA264TLCVG



Heat Recovery (460V – 3 Phase) - (24 TONS) AOUA288TLCVG



See Dip-SW SET5-4 and SET4-1 option on page 36.



Brought to you by **FUJITSU**

Service

BULLETIN

S007D

August 2017

* Dip-SW SET5-4 diagrams are only used with one refrigerant system configuration. When there are more than one refrigerant systems on a communication network, confirm that the setting of Dip-SW SET5-4 complies with the Terminal Resistor requirements in the Installation Manual.

** Dip-SW SET4-1 in all Airstage outdoor units, except V-II 208/230V-3 Phase RLBV, provides a system protection function that is activated by default from the factory. When activated, Dip-SW SET4-1 is ON, the system will shut down whenever an indoor unit fails. If Dip-SW SET4-1 is set to OFF, a failure in an indoor unit will display error and the system will continue its normal operation. The activation of Dip-SW SET4-1 is crucial to VRF equipment protection. Under extreme conditions Fujitsu allows the de-activation of Dip-SW SET4-1 **ONLY AFTER closing the Isolation Valve/Ball Valve** connecting the failed indoor unit to the refrigerant system. Please refer to AE015 Bulletin for Isolation Ball Valves for proper installation of Isolation Ball valves in Heat Pump and Heat Recovery systems. The de-activation of Dip-SW SET4-1 without closing the indoor unit Isolation Valve/Ball Valve shall void the outdoor unit warranty. It is important to activate Dip-SW SET4-1 again immediately after the indoor unit failure has been rectified.